

DURACELL®

KEY FOB BATTERY DISPLAY



252

**TOTAL
BATTERIES
SHIPPED
WITH EACH
DISPLAY**

16.5" H

4" W

13" L

DISPLAY INSTRUCTIONS

1. Press On/Off button; Red, Yellow, Green lights will flash quickly twice. The red light then stays on, the test is ready to start.
2. Hold your key fob to the detector within 3", push any button on your key fob.
3. Look for the flashing lights on the display, as shown above. If you see the yellow or green light, Your key fob battery still has power.
4. If you see the red light, time to replace your key fob battery.
5. Find the right coin or button battery for your device; Visit: DURACELL.COM/COINFINDER

DURACELL®

KEY FOB BATTERY DISPLAY

Each Display Ships with:			Suggested Retail			Total Sales
1	Shipping Case of 2032	(72 Batteries)	x	\$6.99	=	\$503.28
1	Shipping Case of 2025	(72 Batteries)	x	\$6.99	=	\$503.28
1	Shipping Case of 1616	(36 Batteries)	x	\$6.99	=	\$251.64
1	Shipping Case of 2016	(36 Batteries)	x	\$6.99	=	\$251.64
1	Shipping Case of 2450	(36 Batteries)	x	\$6.99	=	\$251.64
			Total Retail	VALUE		\$1,761.48



The built-in BATTERY TESTER provides your customers "how to" instructions for selecting the correct battery.

PROPOSITION 65 WARNING: Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Batteries also contain other chemicals known to the State of California to cause cancer. WASH HANDS AFTER HANDLING.


Full Display Kit:

\$499 - (PN 9700) Includes Key Fob Battery Tester Display, Includes 252 Batteries listed above - ships free. \$50 Discount if ordered with a JT&T Display

Starter Kit:

\$175 - (PN 9701) Includes Key Fob Battery Tester Display, Includes 60 Batteries - 12 of each type. \$25 Discount if ordered with a JT&T Display

Replacement batteries available starting at \$2.08ea, see pricelist for details



Orders@thebestconnection.com
775-322-7000
285 E Parr Blvd, Reno, NV 89512